

Assembly Instructions for Furniture on roses

1. Ensure lock or latch mechanism is fitted centrally & square in the door .
2. Drill 19mm hole in door so that spindle is put through lock follower. Insert spindle ensuring groove/hollow section is aligned with grub screw in lever handle stem.
3. Put lever template on spindle & transfer the drill marking for lever & escutcheon (if used) to the door.
4. Remove lever template & spindle. Drill at marked points on both sides (drill \varnothing 7mm).
5. Put spindle in lock follower & centre it (spindle & bolt through fixings up to max. 45mm door thickness; 54mm spindles provided separately).

Attention:  Insert spindle in this way that the point of the grubscrew can break through the thinnest spot.

6. (For door levers with 3-piece and fixed rose) Pay attention to direction of lever handles before assembling! Fix rose mounting plates (metal) to door & secure with bolt through fixings M4. Put lever handle with base member on spindle & lock at mounting plates. Fix with screw-overring
7. Screw grub screws in both levers & tighten them up (if lock/spindle/fixing screws aren't centred, handle will bind. Remove levers & rose assembly & check lock position. Redrill if necessary)
8. Fix escutcheons & bathroom turns in the same way
9. Check function & press rose covers on.

If you need any further help
please contact 0113 245 9559
/ info@karcherhandles.co.uk

KARCHER

DESIGN